SAMMOBILE

How to flash your Samsung phone?

1 FILE

1. Extract (un-rar) the firmware file (i.e. to folder c:\Odin)
2. Download Odin
3. Extract Odin ZIP file (i.e. to folder c:\Odin)
4. Open Odin
5. Power off your phone
6. Reboot Phone in Download Mode

   Connect USB-cable to your computer. Hold down **Volume up** and **Volume down** at same time. While holding down, connect the USB-cable to your phone
7. Wait until you get a blue sign in Odin
8. Add MD5-file in AP-field in Odin. **Do not tick any extra boxes.** The only options to be ticked are **F. Reset Time and Auto-Reboot.**
9. Click the start button to begin flashing the firmware update

If you have any questions or need help, our moderators on our forum are happy to help you